



THE INNOVATORS OF COMFORT™



## Stressless® Vision

**Size:** Small

**Chair, W:** 31<sup>1</sup>/<sub>2</sub>" **H:** 39<sup>1</sup>/<sub>2</sub>"-43<sup>3</sup>/<sub>4</sub>" **D:** 30"

**Seat Height:** 17<sup>3</sup>/<sub>4</sub>"

**Ottoman:** W: 22<sup>1</sup>/<sub>2</sub>" **H:** 17<sup>1</sup>/<sub>4</sub>" **D:** 19<sup>3</sup>/<sub>4</sub>"

## Stressless® Dream

**Size:** Medium

**Chair, W:** 33<sup>3</sup>/<sub>4</sub>" **H:** 39<sup>3</sup>/<sub>4</sub>"-43<sup>3</sup>/<sub>4</sub>" **D:** 32<sup>1</sup>/<sub>4</sub>"

**Seat Height:** 18"

**Ottoman:** W: 22<sup>1</sup>/<sub>2</sub>" **H:** 17<sup>1</sup>/<sub>4</sub>" **D:** 19<sup>3</sup>/<sub>4</sub>"

## Stressless® Spirit

**Size:** Large

**Chair, W:** 36<sup>1</sup>/<sub>4</sub>" **H:** 39<sup>3</sup>/<sub>4</sub>"-43<sup>3</sup>/<sub>4</sub>" **D:** 32<sup>1</sup>/<sub>4</sub>"

**Seat Height:** 18"

**Ottoman:** W: 22<sup>1</sup>/<sub>2</sub>" **H:** 17<sup>1</sup>/<sub>4</sub>" **D:** 19<sup>3</sup>/<sub>4</sub>"



Adjust the Stressless® Glide wheels to the setting you desire. You can automatically shift to any seating position by simply using your body weight.



The Stressless® Vision, Dream and Spirit can be adjusted to match your height by adding an elevator ring.