

JAZZ, THE NEW FEELING OF STRESSLESS®



THE INNOVATORS OF COMFORT™

Stressless® Jazz

Size: Large

Chair, W: 36¹/₂" **H:** 40-44" **D:** 30¹/₄"

Seat Height: 16", 17³/₄", 19¹/₄"


Ottoman: W: 21¹/₂" **H:** 17³/₄" **D:** 14³/₄"

Size: Medium


Chair, W: 33" **H:** 39-43" **D:** 29¹/₂"

Seat Height: 15³/₄", 17¹/₂", 19"

Ottoman: W: 21¹/₂" **H:** 17³/₄" **D:** 14³/₄"



Adjust the Stressless Glide wheels to the setting you desire. You can automatically shift to any seating position by simply using your body weight.



The Stressless Jazz and ottoman can be adjusted to match your height by adding any of the three height rings.